

Wireless Settings



1. Enter Setting pages

2. Chose the Lan Wireless Settings **Wireless Lan Settings**, then click the

Scan , chose your wifi SSID and write in your wifi password(Share Key):

IP Camera Options	
Network Settings	Wireless Lan Settings
- Basic Network Settings	Wireless Network List
- Wireless Lan Settings	ChinaNet-CFZd[4e00e030050a] infra WPA/WPA2-i suneyes[00008c210a42] infra WPA/WPA2-PSK
- UPnP Settings	<input type="button" value="Scan"/>
- ADSL Settings	Using Wireless Lan <input checked="" type="checkbox"/>
- DDNS Service Settings	SSID suneyes
Alarm Settings	Network Type Infra
Multi-Device Settings	Encryption WPA2 Personal (AES)
System Settings	Share Key suneyes1234
Back	<input type="button" value="Set"/> <input type="button" value="Refresh"/>

3. Click , then remove the LAN Cable waiting for reboot

Network Settings	The device is rebooting. Don't shutdown it's power. Please waiting ... 29
- Basic Network Settings	
- Wireless Lan Settings	
- UPnP Settings	
- ADSL Settings	
- DDNS Service Settings	
Alarm Settings	
Multi-Device Settings	

4. If the IP appear again from the IP Camera Wizard , means your wifi is setting succeed.